



# X-TYPE

## HANDBOOK SUPPLEMENT

This supplement should be used in conjunction with Owner's  
Handbook JJM180220801.

Publication No. JSA180220801


# JaguarVoice

## Introduction

This section should be used to supplement the JaguarVoice section already in your Owner's Handbook.

The system is controlled by the Voice button on the left-hand side of the steering wheel.

## Steering wheel voice switches



1. Message centre display.
2. Voice button.
3. Mode button, on radio.
4. Seek/tuning control, on radio (used to commence voice training).

## Using the System

### Initialisation

JaguarVoice is ready to operate ten seconds after the ignition switch is turned to position **II**, the system is enabled.

## How to Say Numbers

Numbers in voice commands must be given as shown below. Either 'zero' or 'oh' can be used for '0', most users will find that 'zero' gives better results. For information about specific commands, see **Voice Command List**.

# JaguarVoice

---

## Voice Command List

### Display commands (where fitted, front use only)

- DISPLAY ON
- DISPLAY OFF
- [DISPLAY] [SELECT] DAY COLOURS
- [DISPLAY] [SELECT] NIGHT COLOURS
- [DISPLAY] [SELECT] TWILIGHT COLOURS
- [DISPLAY] [SELECT] AUTOMATIC COLOURS
- [DISPLAY] SHOW NAVIGATION
- [DISPLAY] SHOW AUDIO
- [DISPLAY] SHOW CLIMATE CONTROL
- [DISPLAY] SHOW PHONE
- [DISPLAY] HELP

### Navigation commands (where fitted, front use only)

- [NAVIGATION] SHOW DESTINATION
- [NAVIGATION] SHOW [CURRENT] POSITION
- [NAVIGATION] SHOW WHOLE ROUTE
- [NAVIGATION] SHOW NORTH UP  

This will orientate the map display to have North heading towards the top of the screen.
- [NAVIGATION] SHOW (HEAD/HEADING) UP  

This will orientate the map display to have the vehicle heading towards the top of the screen.
- [NAVIGATION] ZOOM IN MAXIMUM  

This will adjust the screen display to show maximum magnification.
- [NAVIGATION] ZOOM OUT MAXIMUM  

This will adjust the screen display to show minimum magnification.
- [NAVIGATION] [SELECT] ROUTE HOME  

This sets a route to the 'home' location. The 'home' location must previously have been stored in the navigation system.
- [NAVIGATION] REROUTE  

This will force a manual recalculation of the route based upon the current position of the vehicle. This can be used when starting a route from an unmapped area when the nearest road selected by the navigation system is not the road used to exit that area.
- [NAVIGATION] VOICE GUIDANCE ON

# JaguarVoice

---

- [NAVIGATION] VOICE GUIDANCE OFF Sets the navigation system route preferences to select the shortest route.
  - [NAVIGATION] REPEAT [LAST] INSTRUCTION
  - [NAVIGATION] ZOOM LEVEL <zoom level>

**Note:** There are 13 zoom levels. Zoom level 1 represents maximum magnification.
  - [NAVIGATION] ZOOM IN <zoom increment level>
  - [NAVIGATION] ZOOM OUT <zoom increment level>
  - [NAVIGATION] CLEAR ROUTE
  - [NAVIGATION] SHOW TURN LIST

Displays details of the next three turns for the route currently set in the navigation system.
  - NAVIGATION STORE NAME

Stores the currently selected location, with a nametag of your choice. The system will prompt you with 'NAME PLEASE', press and release the voice button and give a nametag of your choice, as in the RADIO STORE NAME, see . A total of 20 navigation nametags can be stored.
  - [NAVIGATION] [SELECT] DESTINATION <nametag>
  - [NAVIGATION] ADD WAY POINT <nametag>

A way point is a stop-off or mid-point between your current location and your destination.
  - [NAVIGATION] CLEAR NEXT WAY POINT
  - [NAVIGATION] MINIMISE DISTANCE
  - [NAVIGATION] MINIMISE TIME Sets the navigation system route preferences to select the fastest route.
  - [NAVIGATION] PREFER MAJOR ROADS
  - [NAVIGATION] AVOID MAJOR ROADS
  - [NAVIGATION] PREFER TOLL ROADS
  - [NAVIGATION] AVOID TOLL ROADS
  - [NAVIGATION] PREFER FERRIES
  - [NAVIGATION] AVOID FERRIES
  - NAVIGATION [PLAY] DIRECTORY
  - NAVIGATION DELETE <nametag>
  - NAVIGATION DELETE DIRECTORY

Deletes all currently stored navigation nametags. This will not delete these locations as memory points within the navigation systems memory.
  - NAVIGATION HELP
  - NAVIGATION ROUTE HELP
  - NAVIGATION MEMORY HELP
- Navigation traffic information commands (where available, front use only)**
- NAVIGATION TRAFFIC INFO ON
  - NAVIGATION TRAFFIC INFO OFF

# JaguarVoice

## Navigation nametag features within the navigation system (front use)

To create a new memory point with a nametag at your current position:

- Ensure the display is showing the map. You can do this by giving the command 'NAVIGATION SHOW CURRENT POSITION' command or by pressing the NAV key next to the screen twice.

Press and release the voice button, wait for the end of the beep then give the 'NAVIGATION STORE NAME' command.


After each prompt press and release the voice button, wait until the end of the beep, and then speak.

To create a new memory point with a nametag at any position on the map:

- Ensure the display is showing the map. You can do this by giving the 'NAVIGATION SHOW CURRENT POSITION' command or by pressing the NAV key next to the screen twice
- Scroll the map until the position that you wish to store is in the centre of the display.
- Press and release the voice button, wait for the end of the beep then give the 'NAVIGATION STORE NAME' command.

After each prompt press and release the voice button, wait until the end of the beep, and then speak.

## To list navigation memory points with nametags



JOL3493

- Press the NAV key next to the screen to select the navigation system, if required press again to select the map view.
- Touch the 'Nav Menu' button on the map screen.
- Select 'Stored Locations' on the Nav Menu screen, then 'Memory Points' (see illustration above). The navigation system will now display the total number of memory points that have been stored with nametags.
- Select 'List' this will list all stored memory points (see illustration above). A red square background to the icon indicates the memory point has an associated nametag.

# JaguarVoice

To add a nametag to an existing navigation memory point




JOL3491

- Follow the steps 1–4 shown on the previous page (*to list navigation memory points with nametags*) to list all memory points then select the desired memory point.
- Press and release the voice button, wait for the end of the beep then give the 'NAVIGATION STORE NAME' command.

After each prompt press and release the voice button, wait until the end of the beep, then speak.

To play the nametag associated with a memory point



JOL3492

- Follow steps 1–4 (*to list navigation memory points with nametags*) to list all memory points then select the desired memory point.
- Touch the talking head button (see the previous illustration) to play the nametag.

**To delete a nametag associated with a memory point**

- Follow steps 1–4 (*to list navigation memory points with nametags*) to list all memory points, then select the desired memory point.
- Touch the 'Delete Nametag' button (see the previous illustration) and then confirm.

**Note:** When a memory point is deleted from the navigation system, its nametag is also deleted.